



**R1 = Gate Stopper -> 1 .. 20 OHM**

**R2 = Gate Pulldown -> 10 .. 20 kOHM**

**Z1 = Gate Protection Zener Diode -> 18 .. 20 Volt**

**Values depend on Transistor used.**

**Connect as close to Gate and Emitter / Source as possible.**